


ACHM-5-Parts List



Description	Part#	Stock	Description	Part#	Stock
1. Core.....	101-1001	Stock:	8. Louver.....	101-0004	Stock:
2. Motor	306-3001	Stock:	9. Fan	307-0001	Stock:
3. Top Panel.....	101-0006	Stock:	10. Fan Guard	308-0001	Stock:
4. Bottom Panel	101-0006	Stock	11. Right Panel	101-0002	Stock:
5. Right Tank	101-0047	Stock	12. Left Panel	101-0002	Stock:
6. Left Tank	101-0012	Stock:	13. Back Panel	101-0008	Stock:
7. Motor Bracket	101-0005	Stock:	14. Shaft Adapter....	312-1002	Stock: